




THRU HIKER™ MESH HOUSE SERIES

Assembly Instructions


1 PREPARE FOR SETUP

1. Stake out corners of Mesh House.



2 ATTACH CORD AND STAKE

1. Attach cord over pole and stake out about 5' from corners.



3 SETUP

1. Optional setup under Thru-Hiker 70 or 100 Wing: clip cord to webbing loop at top.



2. Optional setup: suspend from trees to eliminate need for poles.

